4. Buzzer Function

A warning buzzer shown in the below table has been added to the buzzer function.

Function
● S-mode Operation Reject Warning* ● Brake Fluid Low Warning

*: Models with 6-speed automatic transmission

■ FUNCTION OF MAIN COMPONENT

▶ Signal of ECU ◀

ECU	Input Signal
ECM	● Engine speed signal ● Shift position signal*1 ● Current range position signal ● Fuel injection volume signal ● Engine coolant temperature signal ● Buzzer sounding request signal ● Warning light control signal ● Indicator light illumination request signal ● Warning message display request signal ● Eco-Zone indicator level signal ● Ecology light indicator signal ● Information message display request signal ● Diagnosis signal
Headlight Leveling ECU Assembly*2	● Indicator light illumination request signal
Smart Key ECU Assembly*3	● Warning message display request signal ● Information message display request signal ● Buzzer sounding request signal ● Engine immobiliser certification signal ● Emergency request signal
Air Conditioning Amplifier Assembly*4	● Outside temperature signal
Skid Control ECU*5, *6	● Vehicle speed sensor signal ● Warning light control signal ● Indicator light illumination request signal*6 ● Emergency brake signal operation signal*6 ● Diagnosis signal
Air Bag Sensor Assembly*7	● SRS warning signal ● Diagnosis signal

*1: Models with A/T
*2: Models with LED headlight assembly
*3: Models with entry and start system
*4: Models with air conditioning system
*5: Models with ABS
*6: Models with VSC
*7: Models with SRS airbag system