ABBREVIATIONS

The following abbreviations are used in this manual.

A/C	=	Air Conditioner
A/T	=	Automatic Transaxle
ABS	=	Anti–Lock Brake System
ACIS	=	Acoustic Control Induction System
ACM	=	Active Control Engine Mount
BEAN	=	Body Electronics Area Network
CAN	=	Controller Area Network
DLC3	=	Data Link Connector 3
ECT	=	Electronic Control Transmission
ECU	=	Electronic Control Unit
EFI	=	Electronic Fuel Injection
ESA	=	Electronic Spark Advance
EVAP	=	Evaporative Emission
FL	=	Fusible Link
INT	=	Intermittent
J/B	=	Junction Block
LH	=	Left–Hand
O/D	=	Overdrive
R/B	=	Relay Block
RH	=	Right–Hand
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
VSC	=	Vehicle Stability Control
VSV	=	Vacuum Switching Valve
VVT	=	Variable Valve Timing
w/	=	With
w/o	=	Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.