F RELAY LOCATIONS

: Engine Room J/B	Engine Compartment Left (See Page 21)

* 1:H-LP RH UPR
* 2:H-LP LH UPR

