J POWER SOURCE (Current Flow Chart)

Engine Room R/B (See Page 22)

Fuse		System	Page
7.5A	ABS3	ABS	146
7.5A	CRT	Navigation System	220
7.5A	STARTER	Engine Control	68
		Starting and Ignition	60
10A	EFI NO,2	Engine Control	68
10A	ETCS	Cruise Control	132
		ECT and A/T Indicator	84
		Engine Control	68
15A	H–LP LH LWR	Headlight	92
15A	H–LP RH LWR	Headlight	92
15A	RR HTR	Rear Heater	248
25A	A/F	Engine Control	68

Engine Room J/B (See Page 26)

Fuse		System	Page
7.5A	ALT–S	Charging	64
7.5A	ECU–B	Air Conditioner	242
		Automatic Light Control	120
		Charging	64
		Combination Meter	230
		Cruise Control	132
		Door Lock Control	158
		ECT and A/T Indicator	84
		Engine Control	68
		Engine Immobilizer System	82
		Front Fog Light	96
		Headlight	92
		Interior Light	110
		Light Auto Turn Off System	122
		Multiplex Communication System (CAN)	218
		Navigation System	220
		Power Window	152
		Seat Belt Warning	194
		Sliding Roof	186
		SRS	125
		Theft Deterrent System	176
		VSC	140
		Wireless Door Lock Control	166
10A	DOME	Combination Meter	230
		Cruise Control	132
		ECT and A/T Indicator	84
		Engine Control	68

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	DOME	Front Fog Light	96
		Illumination	116
		Interior Light	110
		Navigation System	220
		Theft Deterrent System	176
		Wireless Door Lock Control	166
10A	H–LP LH UPR	Headlight	92
10A	H–LP RH UPR	Combination meter	230
		Headlight	92
10A	HORN	Horn	208
		Theft Deterrent System	176
15A	HAZARD	Turn Signal and Hazard Warning Light	102
15A	SECURITY	Theft Deterrent System	176
20A	EFI NO,1	Cruise Control	132
		ECT and A/T Indicator	84
		Engine Control	68
25A	DOOR LOCK	Door Lock Control	158
		Theft Deterrent System	176
		Wireless Door Lock Control	166
25A	RAD NO.1	Audio System	226
40A	MAIN	Automatic Light Control	120
		Headlight	92
		Light Auto Turn Off System	122
		Theft Deterrent System	176

Instrument Panel J/B (See Page 28)

Fuse		System	Page
7.5A	IG1	ABS	146
		Automatic Light Control	120
		Back–Up Light	108
		Cruise Control	132
		Door Lock Control	158
		ECT and A/T Indicator	84
		Front Fog Light	96
		Headlight	92
		Interior Light	110
		Light Auto Turn Off System	122
		Navigation System	220
		Power Window	152
		Seat Belt Warning	194
		Sliding Roof	186
		Theft Deterrent System	176
		Turn Signal and Hazard Warning Light	102
		Wireless Door Lock Control	166

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	OBD	Engine Control	68
7.5A	PANEL	Illumination	116
7.5A	RAD NO.2	Audio System	226
		Automatic Light Control	120
		Door Lock Control	158
		Headlight	92
		Interior Light	110
		Navigation System	220
		Power Window	152
		Remote Control Mirror	206
		Seat Belt Warning	194
		Shift Lock	198
		Theft Deterrent System	176
		Wireless Door Lock Control	166
10A	ECU–IG	ABS	146
		Charging	64
		Multiplex Communication System (CAN)	218
		Navigation System	220
		Shift Lock	198
		Theft Deterrent System	176
		VSC	140
10A	HEATER	ABS	146
		Air Conditioner	242
		Charging	64
		Combination Meter	230
		Cruise Control	132
		ECT and A/T Indicator	84
		Engine Control	68
		Front Fog Light	96
		Illumination	116
		Interior Light	110
		Navigation System	220
		Radiator Fan and Condenser Fan	238
		Rear Heater	248
		Rear Window Defogger	214
		Seat Belt Warning	194
		SRS	125
		VSC	140
10A	IGN	ABS	146
		Combination Meter	230
		Cruise Control	132
		ECT and A/T Indicator	84
		Engine Control	68
		Engine Immobilizer System	82

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	IGN	SRS	125
		VSC	140
10A	TAIL	Front Fog Light	96
		Taillight	100
15A	CIG	Cigarette Lighter	210
15A	IG2	Engine Control	68
		Starting and Ignition	60
15A	PWR OUTLET1	Power Outlet	212
15A	RR WIP	Rear wiper and Washer	192
20A	D RR DOOR	Power Window	152
20A	FR FOG	Front Fog Light	96
20A	P FR DOOR	Interior Light	110
		Power Window	152
20A	P RR DOOR	Power Window	152
20A	S/ROOF	Sliding Roof	186
20A	STOP	ABS	146
		Cruise Control	132
		ECT and A/T Indicator	84
		Engine Control	68
		Shift Lock	198
		Stop Light	106
		VSC	140
20A	WASHER	Front Wiper and Washer	188
		Rear wiper and Washer	192
25A	D FR DOOR	Door Lock Control	158
		Interior Light	110
		Power Window	152
		Theft Deterrent System	176
		Wireless Door Lock Control	166
25A	WIPER	Front Wiper and Washer	188
30A	POWER	Power Seat (Driver’s Seat)	200
		Power Seat (Front Passenger’s Seat)	204
40A	AM1	Power Outlet	212
		Starting and Ignition	60

Fusible Link Block (See Page 25)

Fuse		System	Page
30A	ABS1	VSC	140
30A	AM2	Starting and Ignition	60
30A	CDS	Radiator Fan and Condenser Fan	238
30A	RDI	Radiator Fan and Condenser Fan	238
30A	RR DEF	Rear Window Defogger	214
40A	ABS1	ABS	146

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
40A	ABS2	ABS	146
		VSC	140
50A	HTR	Air Conditioner	242
140A	ALT	Automatic Light Control	120
		Charging	64
		Front Fog Light	96
		Illumination	116
		Light Auto Turn Off System	122
		Power Outlet	212
		Power Seat (Driver's Seat)	200
		Power Seat (Front Passenger's Seat)	204
		Radiator Fan and Condenser Fan	238
		Starting and Ignition	60
		Taillight	100
		Theft Deterrent System	176

* These are the page numbers of the first page on which the related system is shown.