L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980–11070
A 2	A/C Lock Sensor	90980–11016
	A/C Magnetic Clutch	
A 3	A/T Indicator SW	90980–12362
	Back–Up Light SW	
	Neutral Start SW	
A 4	ABS Actuator	90980–12116
A 5	ABS Speed Sensor Front LH	90980–11075
A 6	ABS Speed Sensor Front RH	
A 7	Air Flow Meter	90980–11317
A 8	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980–11178
A 9	Air Fuel Ratio Sensor (Bank 2 Sensor 1)	
A10	Airbag Sensor Front LH	90980–11856
A11	Airbag Sensor Front RH	
A12	Alternator	90980–11964
A13	Alternator	90980–09365
A14	A/C Control Assembly	90980–11392
A15	A/C Control Assembly	90980–11391
A16	A/C Room Temp. Sensor	90980–11918
A17	A/C Solar Sensor	
A18	A/C Thermistor	
A20	Accelerator Pedal Position Sensor	90980–11858
A21	Air Inlet Control Servo Motor	90980–11909
A22	Air Mix Control Servo Motor	
A23	Air Vent Mode Control Servo Motor	
A24	Airbag Sensor Assembly (w/ Side Airbag)	82824–50160
	Airbag Sensor Assembly (w/o Side Airbag)	90980–11869
A25	Airbag Sensor Assembly	90980–11872
A26	Airbag Sensor Assembly (w/ Side Airbag)	82824–50150
	Airbag Sensor Assembly (w/o Side Airbag)	90980–11867
A27	Airbag Squib (Front Passenger Airbag Assembly)	90980–12160
A28	Airbag Squib (Steering Wheel Pad)	
A29	Ashtray Illumination	90980–10824
A30	Automatic Light Control Sensor	90980–11107
A31	ABS Deceleration Sensor	90980–10845
A32	ABS Speed Sensor Rear LH	90980–11060
A33	ABS Speed Sensor Rear RH	
B 1	Brake Warning SW	90980–11207
B 2	Blower Motor	90980–10385
B 3	Blower Motor Controller	90980–11676
B 4	Body ECU	90980–11957
B 5	Body ECU	90980–11956
B 6	Body ECU	90980–11955
B 7	Body ECU	90980–11954
B 8	Brake Pedal Load Sensing SW	90980–10860
B 9	Back Door Key Lock and Unlock SW	90980–11489

Code	Part Name	Part Number
B10	Back Door Lock Motor	90980–11292
	Back Door Unlock Detection SW	
B11	Buckle SW (Front Passenger's Side)	90980–12366
B12	Buckle SW RH	90980–10942
	Seat Position Airbag Sensor RH	
C 1	Camshaft Timing Control Valve LH	90980–11162
C 2	Camshaft Timing Control Valve RH	
C 3	Condenser Fan Motor	90980–10928
C 4	Counter Gear Speed Sensor	90980–11156
C 5	Crankshaft Position Sensor	90980–10947
C 6	Cigarette Lighter	90980–10760
C 7	Cigarette Lighter Illumination	90980–11148
C 8	Combination Meter	90980–11392
C 9	Combination Meter	90980–11391
C10	Combination SW	90980–11671
C11	Combination SW	90980–11594
C12	Combination SW	90980–12183
C13	Curtain Shield Airbag Squib LH	90980–12219
C14	Curtain Shield Airbag Squib RH	
D 1	Diode (Cooling Fan)	90980–10962
D 2	DLC3	90980–11978
D 3	Diode (Rear Interior Light)	90980–10962
D 4	Door Courtesy Light Front LH	90980–11148
D 5	Door Courtesy Light Front RH	
D 6	Door Courtesy SW Front LH	90980–10871
D 7	Door Courtesy SW Front RH	
D 8	Door Courtesy SW Rear LH	
D 9	Door Courtesy SW Rear RH	
D10	Door Key Lock and Unlock SW Front LH	90980–11858
	Door Lock Motor Front LH	
	Door Unlock Detection SW Front LH	
D11	Door Key Lock and Unlock SW Front RH	
	Door Lock Motor Front RH	
	Door Unlock Detection SW Front RH	
D12	Door Lock Motor Rear LH	90980–11150
	Door Unlock Detection SW Rear LH	
D13	Door Lock Motor Rear RH	
	Door Unlock Detection SW Rear RH	
E 1	ECT Solenoid	90980–12326
E 2	EFI Water Temp. Sensor	90980–10737
E 3	Engine Hood Courtesy SW	90980–11189
E 4	ECT Pattern Select SW	90980–10797
E 5	Engine and ECT ECU	90980–12142
E 6	Engine and ECT ECU	90980–12146
E 7	Engine and ECT ECU	90980–12144
E 8	Engine and ECT ECU	90980–12145

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
E 9	Engine and ECT ECU	90980–12143
F 1	Front Clearance Light LH	90980–11156
F 2	Front Clearance Light RH	
F 3	Front Fog Light LH	90980–11660
F 4	Front Fog Light RH	
F 5	Front Side Turn Signal Light LH	90980–11162
F 6	Front Side Turn Signal Light RH	
F 7	Front Turn Signal Light LH	90980–11019
F 8	Front Turn Signal Light RH	
F 9	Front Washer Motor	
F10	Front Wiper Motor	90980–11599
F11	Fusible Link Block	–
F12	Front Door Speaker LH	90980–10935
F13	Front Door Speaker RH	
F14	Fuel Pump	90980–11077
	Fuel Sender	
G 1	Gateway ECU	90980–11911
G 2	Glove Box Light	90980–11098
H 1	Headlight LH (High)	90980–11659
H 2	Headlight LH (Low)	90980–11660
H 3	Headlight RH (High)	90980–11659
H 4	Headlight RH (Low)	90980–11660
H 5	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980–11930
H 6	Horn LH	90980–10619
H 7	Horn RH	
H 8	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980–11929
H 9	Heater Relay	82660–44010
H10	High Mounted Stop Light	90980–11148
I 1	Ignition Coil and Igniter No.1	90980–11885
I 2	Ignition Coil and Igniter No.2	
I 3	Ignition Coil and Igniter No.3	
I 4	Ignition Coil and Igniter No.4	
I 5	Ignition Coil and Igniter No.5	
I 6	Ignition Coil and Igniter No.6	
I 7	Injector No.1	90980–11153
I 8	Injector No.2	
I 9	Injector No.3	
I10	Injector No.4	
I11	Injector No.5	
I12	Injector No.6	
I13	Ignition SW	90980–11615
I14	Interior Light	90980–10908
I15	Ignition Key Cylinder Light	90980–12092
	Transponder Key Amplifier	

Code	Part Name	Part Number
I16	Indicator Light Wire Sub Assembly	90980–12221
	Transmission Control SW	
	Transmission Shift Main SW	
J 1	Junction Connector	90980–11194
J 2	Junction Connector	
J 3	Junction Connector	
J 4	Junction Connector	
J 5	Junction Connector	90980–11542
J 6	Junction Connector	90980–11915
J 7	Junction Connector	90980–11542
J 8	Junction Connector	90980–11915
J 9	Junction Connector	
J10	Junction Connector	90980–10807
J11	Junction Connector	
J12	Junction Connector	90980–11915
J13	Junction Connector	90980–10976
J14	Junction Connector	90980–11542
J15	Junction Connector	
J16	Junction Connector	
J17	Junction Connector	90980–12374
J18	Junction Connector	
J19	Junction Connector	
J20	Junction Connector	
K 1	Knock Sensor 1	90980–11875
K 2	Knock Sensor 2	
K 3	Key Interlock Solenoid	90980–10795
	Unlock Warning SW	
L 1	License Plate light	90980–11300
M 1	Multi–Display	90980–12203
M 2	Multi–Display	90980–12410
N 1	Noise Filter (Ignition System)	90980–10843
N 2	Navigation ECU	90980–11973
N 3	Navigation ECU	90980–11923
N 4	Noise Filter (Rear Window Defogger)	90980–10860
N 5	Noise Filter (Stop Light)	90980–10916
N 6	Noise Filter (Stop Light)	90980–10915
O 1	Oil Pressure SW	90980–11363
O 2	Overhead J/B	90980–12183
P 1	Power Steering Oil Pressure SW	90980–11428
P 2	Pressure SW	90980–10943
P 3	Parking Brake SW	90980–10871
P 4	Power Outlet (Front)	90980–10760
P 5	Power Window Master SW with ECU	90980–12166

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
P 6	Power Window Motor Front LH	90980–10797
P 7	Power Window Motor Front RH	
P 8	Power Window Motor Rear LH	
P 9	Power Window Motor Rear RH	
P10	Power Window SW Front LH	90980–10799
P11	Power Window SW Rear LH	
P12	Power Window SW Rear RH	
P13	Pretensioner LH	90980–12253
P14	Pretensioner RH	
P15	Power Seat Control SW (Driver's Seat Lumbar Support Control)	90980–10789
P16	Power Seat Control SW (Driver's Seat)	90980–10997
P17	Power Seat Control SW (Front Passenger's Seat)	
P18	Power Seat Motor (Driver's Seat Front Vertical Motor)	90980–10825
P19	Power Seat Motor (Driver's Seat Lifter Control)	
P20	Power Seat Motor (Driver's Seat Lumbar Support Control)	
P21	Power Seat Motor (Driver's Seat Reclining Control)	
P22	Power Seat Motor (Driver's Seat Slide Control)	
P23	Power Seat Motor (Front Passenger's Reclining Control)	
P24	Power Seat Motor (Front Passenger's Seat Slide Control)	
R 1	Radiator Fan Motor	90980–10928
R 2	Rear Washer Motor	90980–11051
R 3	Radio and Player	90980–10996
R 4	Radio and Player	90980–10997
R 5	Radio and Player	90980–10803
R 6	Rear Heater Main SW	90980–10933
R 7	Remote Control Mirror SW	90980–11657
R 8	Rear Combination Light LH	90980–10797
R 9	Rear Combination Light RH	
R10	Rear Door Speaker LH	90980–10935
R11	Rear Door Speaker RH	
R12	Rear Heater Blower Motor	90980–10795
R13	Rear Heater Blower SW	90980–11527
R14	Rear Heater Relay	82660–53010
R15	Rear Interior Light	90980–10908
R16	Rear Interior Light SW	90980–10860
R17	Rear Power Outlet	90980–10760
R18	Rear Window Defogger	90980–11259
R19	Rear Window Defogger	
R20	Rear Wiper Motor	90980–10908

Code	Part Name	Part Number
R21	Remote Control Mirror LH	90980–10798
R22	Remote Control Mirror RH	
S 1	Skid Control ECU with Actuator	90980–12297
S 2	Starter	90980–11400
S 3	Starter	90980–09463
S 4	Shift Lock ECU	90980–11319
S 5	Short Connector	90980–12366
S 6	Short Connector	90980–12365
S 7	Short Connector	90980–10859
S 8	Short Connector	90980–10860
S 9	Skid Control ECU	90980–11390
S10	Skid Control ECU	90980–11392
S11	Skid Control ECU	90980–11391
S12	Steering Sensor	82824–45030
S13	Stop Light SW	90980–11118
S14	Side Airbag Sensor Front LH	90980–12225
S15	Side Airbag Sensor Front RH	
S16	Side Airbag Sensor Rear LH	
S17	Side Airbag Sensor Rear RH	
S18	Side Airbag Squib LH	90980–11864
S19	Side Airbag Squib RH	
S20	Sliding Roof Control ECU	90980–10801
T 1	Theft Deterrent Horn	90980–10619
T 2	Throttle Control Motor and Sensor	90980–11858
T 3	Turbine Speed Sensor	90980–11156
T 4	Theft Deterrent ECU	90980–12169
T 5	Theft Deterrent Indicator Light	90980–12063
T 7	Transponder Key Computer	90980–11911
T 8	Turn Signal Flasher	90980–10799
T 9	Tweeter LH	90980–11013
T10	Tweeter RH	
V 1	VSV (ACIS No.2)	90980–11149
V 2	VSV (ACM)	90980–11156
V 3	VSV (EVAP)	
V 4	VVT Sensor LH	90980–10947
V 5	VVT Sensor RH	
V 6	VSC Warning Buzzer	90980–10906
V 7	Vanity Light LH	90980–11369
V 8	Vanity Light RH	
W 1	Washer Level Sensor	90980–11068
W 2	Water Temp. SW No.1	90980–11235
W 3	Water Temp. SW No.2	90980–11243
W 4	Wireless Door Lock Buzzer	90980–11142
W 5	Wireless Door Lock ECU	90980–11909
Y 1	Yaw Rate Sensor	90980–11904

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number