SFI SYSTEM (3MZ–FE)

05JY7–01

PRECAUTION

NOTICE:

When disconnecting the negative (–) battery cable, initialize the following systems after the completion of the operation.

System Name	See page
Power Window Control System	05–990
Sliding Roof System	05–1122

NOTICE:

Perform the RESET MEMORY (AT initialization) when replacing the automatic transaxle assembly, engine assembly or ECM.

HINT:

Initialization can not be completed by only removing the battery.