05JXD–01

CHECK FOR INTERMITTENT PROBLEMS

Hand–held tester only:

By putting the vehicle's ECM in the check mode, the 1 trip detection logic is possible instead of the 2 trip detection logic, and the sensitivity to detect faults is increased. This makes it easier to detect intermittent problems.

(a) Clear the DTCs (See page 05–17).

(b) Set the check mode (See page 05–18).

(c) Perform a simulation test (See page 01–23).

(d) Check the connector and terminal (See page 01–33).

(e) Wiggle the harness and the connector (See page 01–33).