054JF–17

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Engine does not crank (Does not start)	1. Starter 2. Starter relay 3. Park/neutral position switch	19–6 19–6 40–7
No initial combustion (Does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05–151 05–155 01–33
No complete combustion (Does not start)	1. Fuel pump control circuit	05–155
Engine cranks normally but difficult	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05–117 05–155 14–1
Difficult to start with cold engine	1. Starter signal circuit 2. Fuel pump control circuit	05–117 05–155
Difficult to start with hot engine	1. Starter signal circuit 2. Fuel pump control circuit	05–117 05–155
High engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05–496 05–151
Low engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05–496 05–155
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit	14–1 05–155
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05–151 05–155
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty	05–155 05–359
Surging (Poor driveability)	1. Fuel pump control circuit	05–155
Engine stalls soon after starting	1. Fuel pump control circuit	05–155
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	05–496 01–33