| DTC | P0121 | THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE PROBLEM |
|---|---|---|

HINT:
This is the purpose of the "throttle position sensor".

## CIRCUIT DESCRIPTION

Refer to DTC P0120 on page 05–67.

| DTC No. | DTC Detection Condition | Trouble Area |
|---|---|---|
| P0121 | Condition (a) continues for 2.0 seconds:<br>(a) Difference between VTA1 and VTA2 deviates from threshold | Throttle position sensor |

## INSPECTION PROCEDURE

HINT:
Read freeze frame data using the hand–held tester. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air–fuel ratio was lean or rich, and other data from the time the malfunction occurred.

| REPLACE THROTTLE BODY ASSY (See page 10–7) |
|---|