DTC C1223/43 ABS CONTROL SYSTEM MALFUNCTION

CIRCUIT DESCRIPTION

HINT:

- This DTC is output when the VSC system detects a malfunction in the ABS system.
- When DTC C1223/43 is memorized, there is no malfunction in the skid control ECU.

DTC No.	DTC Detecting Condition	Trouble Area
C1223/43	Malfunction in ABS control system	ABS control system

INSPECTION PROCEDURE

1	CHECK DTC(FOR ABS SYSTEM)

(a) Clear the DTCs (see page 05–234).
(b) Turn the ignition switch to the ON position.
(c) Are the same DTCs recorded?

NO → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–253)**

YES

REPAIR CIRCUIT INDICATED BY OUTPUT DTC