ELECTRONIC CONTROLLED AUTOMATIC TRANSAXLE [ECT]

PRECAUTION

05CVL–03

NOTICE:

Perform the RESET MEMORY (AT initialization) when replacing the automatic transaxle assy, engine assy or ECM (see page 05–355).

HINT:

Initialization can not be completed by only disconnecting the battery terminal.