05JPL–01

# DATA LIST/ACTIVE TEST

HINT:

By accessing the DATA LIST displayed by the hand–held tester, you can perform such functions as reading the values of switches and sensors without removing any parts. Reading the DATA LIST is the first step of troubleshooting and is one method to shorten labor time.

(d) Connect the hand–held tester to the DLC3.

(e) Turn the ignition switch to the ON position.

(f) Following the display on the tester screen, read the ”DATA LIST”.

**1. DATA LIST FOR AIRBAG SENSOR ASSY CENTER**

| Item | Measurement Item/ Range (Display) | Normal Condition | Diagnostic Note |
|---|---|---|---|
| D SEAT POSITION | Seat position (Driver side)/<br>FORWARD: Seat position is forward<br>BKWARD: Seat position is rearward<br>FAIL: A failure is detected | FORWARD/BKWARD | – |
| PASSENGER CLASS | Passenger classification/<br>NG: A date is not determined<br>NONE: Vacant<br>CHILD: Child (less than 36 kg (79.37 lb)) is seated<br>SMALL: Adult (36 to 54 kg (79.37 to 119.05 lb)) is seated<br>REGULAR: Adult (more than 54 kg (119.05 lb)) is seated<br>FAIL: A failure is detected | NG/NONE/CHILD/SMALL/ REGULAR | – |
| D BUCKLE SW | Buckle switch (Driver side)/<br>ON: The seat belt is fastened<br>OFF: The seat belt is not fastened<br>NG: A data is not determined | ON/OFF | – |
| P BUCKLE SW | Buckle switch (Passenger side)/<br>ON: The seat belt is fastened<br>OFF: The seat belt is not fastened<br>NG: A data is not determined | ON/OFF | – |
| #CODES | Number of past DTC recorded/<br>Min.: 0, Max.: 255 | 0 | – |