050YH–26

PROBLEM SYMPTOMS TABLE

HINT:

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See Page
When the ignition switch is in the ON position, the SRS warning light sometimes comes on after approximately 6 seconds.	SRS warning light circuit malfunction (Always lights up, when DTC is not output).	05–714
SRS warning light always comes on even when DTC is not position.	SRS warning light circuit malfunction (Always lights up, when DTC is not output).	05–714
With the ignition switch in the ON position, the SRS warning light does not come on.	SRS warning light circuit malfunction (Does not light up, when ignition switch is turned to the ON position).	05–718
Although a SRS warning light operates normal, DTC or a normal system code is not displayed.	TC Terminal Circuit	05–1250
Although terminals TC and CG are not connected, DTC or a normal system code is displayed.	TC Terminal Circuit	05–1250