DTC	B1181/18	OPEN IN D SQUIB (DUAL STAGE – 2ND STEP) CIRCUIT

CIRCUIT DESCRIPTION

The D squib (Dual stage – 2nd step) circuit consists of the airbag sensor assy center, the spiral cable sub–assy and the horn button assy.

The circuit instructs the SRS to deploy when deployment conditions are met.

DTC B1181/18 is recorded when an open circuit is detected in the D squib (Dual stage – 2nd step) circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B1181/18	• Open circuit in D2+ wire harness or D2– wire harness of D squib (Dual stage – 2nd step) • D squib (Dual stage – 2nd step) malfunction • Spiral cable sub–assy malfunction • Airbag sensor assy center malfunction	• Horn button assy (D squib, Dual stage – 2nd step) • Spiral cable sub–assy • Airbag sensor assy center • Cowl wire

WIRING DIAGRAM

See page 05–682.

INSPECTION PROCEDURE

1	CHECK D SQUIB CIRCUIT(DUAL STAGE – 2ND STEP, AIRBAG SENSOR ASSY CENTER – HORN BUTTON ASSY)



(a) Turn the ignition switch to the LOCK position.

(b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.

(c) Disconnect the connectors from the airbag sensor assy center and the horn button assy.

(d) Measure the resistance according to the value(s) in the table below.


Standard:

Tester connection	Condition	Specified condition
D2+ – D2–	Always	Below 1 Ω

NG → **Go to step 4**

OK

2 CHECK AIR BAG SENSOR ASSY CENTER



(a) Connect the connector to the airbag sensor assy center.
(b) Using a service wire, connect D2+ and D2– of connector "E".

NOTICE:

- **Twist the end of the service wire in order to insert it into the connector.**
- **Do not forcibly insert the twisted service wire into the terminals of the connector when connecting.**

(c) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
(d) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
(e) Clear the DTCs stored in memory (see page 05–513).
(f) Turn the ignition switch to the LOCK position.
(g) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
(h) Check the DTCs (see page 05–513).

OK:

DTC B1181/18 is not output.


HINT:

Codes other than code B1181/18 may be output at this time, but they are not related to this check.

NG → **REPLACE AIR BAG SENSOR ASSY CENTER**

OK

3 CHECK HORN BUTTON ASSY(D SQUIB, DUAL STAGE – 2ND STEP)



(a) Turn the ignition switch to the LOCK position.
(b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
(c) Disconnect the service wire from connector "E".
(d) Connect the connectors to the horn button assy.
(e) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
(f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
(g) Clear the DTCs stored in memory (see page 05–513).
(h) Turn the ignition switch to the LOCK position.
(i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
(j) Check the DTCs (see page 05–513).

OK:

DTC B1181/18 is not output.

HINT:

Codes other than code B1181/18 may be output at this time, but they are not related to this check.

NG → **REPLACE HORN BUTTON ASSY**


OK

USE SIMULATION METHOD TO CHECK

HINT:

- Before performing the simulation method, check that the airbag sensor assy center is in check mode (see page 05–516).
- Perform the simulation method by selecting the check mode with the hand–held tester (see page 05–516).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05–516).

4 CHECK COWL WIRE



(a) Disconnect the cowl wire connector from the spiral cable sub–assy.

(b) Measure the resistance according to the value(s) in the table below.


Standard:

Tester connection	Condition	Specified condition
A28–4 (D2+) – A28–3 (D2–)	Always	Below 1 Ω

NG → **REPAIR OR REPLACE COWL WIRE**

OK

5 CHECK SPIRAL CABLE SUB–ASSY



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
D2+ – D2–	Always	Below 1 Ω

NG → **REPLACE SPIRAL CABLE SUB–ASSY**

OK

USE SIMULATION METHOD TO CHECK

HINT:

- Before performing the simulation method, check that the airbag sensor assy center is in check mode (see page 05–516).
- Perform the simulation method by selecting the check mode with the hand–held tester (see page 05–516).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05–516).