05JVU–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Seat belt warning lamp for driver seat does not operate	1. Airbag sensor assy center 2. Combination meter assy 3. Front seat inner belt assy RH 4. Wire harness	05–728
Seat belt warning lamp for passenger seat does not operate	1. Front seat inner belt assy LH 2. Occupant detection sensor 3. Multiplex network body ECU 4. Integration control and panel assy (Air conditioner amplifier assy)*1 5. Multi–display*2 6. Wire harness	05–731

HINT:

*1: w/o Navigation system

*2: w/ Navigation system