05JRX–01

CUSTOMIZE PARAMETERS

HINT:

The followings are the possible items to be customized.

NOTICE:

- **After confirming whether the items of the customer's request is applicable or not for the customized items, perform the customize operation.**
- **Be sure to record the current value before customizing.**
- **In case of performing the troubleshooting, pay attention as there is a possibility that the function is OFF by customizing. (Example: In case of the symptom in which "The wireless operation does not function", check that the wireless operation is not OFF by customizing, then perform the troubleshooting.)**

ILLUMINATED ENTRY

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
I/L ON / UNLOCK (Interior light ON w/ door key unlock)	ON	Function to light up the interior light*, ignition light and step light when unlocking with the door key cylinder. *: Interior light comes on when the interior light switch is at the DOOR position.	ON / OFF
LIGHTING TIME (Lighting Time)	15 s	To change the lighting time after closing the door. (It will quickly fade out in case of turning the ignition ON.)	7.5 s / 15 s / 30 s

LIGHT CONTROL

HINT:

Sensitivity adjustment can hardly be confirmed. Please check by customer's actual driving.

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
RESPONSE TIME (Response time)	0.1 s	To change the delay timing of lighting the taillight when going into the tunnel in case that the light control switch is at AUTO position.	1.0 s / 0.1 s
SENSITIVITY (Turn ON luminous intensity)	NORMAL	To adjust the sensitivity of the lighting illumination. Refer to the *1 illustration.	DARK2 / DARK1 / NORMAL / LIGHT1 / LIGHT2

Illustration of *1

Lighting brightness	**Dark** ◄——————————► **Bright**
Setting	DARK2 —— DARK1 —— NORMAL —— LIGHT1 —— LIGHT2