05JS0–01

DTC CHECK/CLEAR

1. DTC CHECK

(a) Connect the intelligent tester II to the DLC3.

(b) Turn the ignition switch to the ON position.

(c) Read DTCs by following the prompts on the tester screen.

HINT:

Please refer to the intelligent tester II operator's manual for further details.

2. DTC CLEAR

(a) DTC can be erased by operating the intelligent tester II.

HINT:

Please refer to the intelligent tester II operator's manual for further details.