0549M–1

PROBLEM SYMPTOMS TABLE

RADIO RECEIVER ASSY

Symptom	Suspect Area	See page
Pressing power switch does not start system.	1. Power source circuit (radio receiver assy) 2. Radio Receiver assy	05–823 67–5
Turning on light switch does not light up night time illumination of radio receiver.	1. Illumination circuit 2. Radio receiver assy	05–825 67–5
All sound can not be heard.	1. Power source circuit (radio receiver assy) 2. Speaker circuit 3. Radio receiver assy	05–823 05–829 67–5
Front speaker (driver side) only is not heard. (volume is too low)	1. Power source circuit (radio receiver assy) 2. Speaker circuit (driver side) *1	05–823 05–832
Sound quality is bad in all modes. (volume is too low)	1. Power source circuit (radio receiver assy) 2. Speaker circuit 3. Sound quality is bad in all modes (volume is too low)	05–823 05–829 05–848
Noise occurs.	–	05–837
Radio broadcast cannot be received. (bad reception)	–	05–849
CD cannot be inserted or is ejected right after insertion.	1. Power source circuit (radio receiver assy) 2. CD cannot be inserted or is ejected right after insertion	05–823 05–838
CD cannot be ejected.	1. Power source circuit (radio receiver assy) 2. CD cannot be ejected	05–823 05–840
Sound quality is bad only when playing CD. (volume is too low)	–	05–841
CD sound skips.	–	05–842
Cassette tape cannot be inserted or played.	1. Power source circuit (radio receiver assy) 2. Cassette tape cannot be inserted or played	05–823 05–844
Cassette tape cannot be ejected.	1. Power source circuit (radio receiver assy) 2. Cassette tape cannot be ejected	05–823 05–845
Sound quality is bad only when playing tape.	–	05–846
Tape is tangled due to incorrect tape speed or auto–reverse malfunction.	–	05–847

*1 w/ Navigation system