CASSETTE TAPE CANNOT BE INSERTED OR PLAYED

INSPECTION PROCEDURE

1	CHECK FOR ANY FOREIGN OBJECT

(a) Check for any foreign objects.
(1) Check that no foreign objects or defects are detected in the cassette tape player of the radio receiver assembly.
OK: No foreign objects or defects are detected.

NG → **REMOVE FOREIGN OBJECT**

OK

2	CHECK CASSETTE TAPE

(a) Check the cassette tape.
(1) Check that the cassette tape is a normal tape with music or voice recorded.
OK: Proper cassette tape with music or voice recorded.

NG → **CASSETTE TAPE IS FAULTY**

OK

3	REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

(a) Replace the cassette tape with another one and recheck.
(1) Replace the cassette tape with another normal one to see if the same trouble occurs again.
OK: The function returns to be normal.

NG → **REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)**

OK

CASSETTE TAPE IS FAULTY