CASSETTE TAPE CANNOT BE EJECTED

INSPECTION PROCEDURE

1	PRESS "EJECT" AND CHECK OPERATION

(a) Press "EJECT" and check the operation.
(1) Press the cassette tape EJECT switch of the radio receiver assembly for 2 seconds or more and check that the cassette tape is ejected.
OK: The cassette tape is ejected.

NG → **REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)**

OK

2	CHECK CASSETTE TAPE

(a) Check the cassette tape.
(1) Check that the ejected cassette tape does not have a peeled label, a cassette body deformation or any other defects.
OK: No fault on the cassette tape.

NG → **CASSETTE TAPE IS FAULTY**

OK

3	REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

(a) Replace the cassette tape with another and recheck.
(1) Replace the cassette tape with another normal one to see if the same trouble occurs again.
OK: Malfunction disappears.

NG → **REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)**

OK

CASSETTE TAPE IS FAULTY