
POWER SOURCE CIRCUIT (NAVIGATION ECU)

CIRCUIT DESCRIPTION


This circuit provides power to the navigation ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	INSPECT NAVIGATION ECU (+B, ACC, GND1)



(a) Disconnect the navigation ECU connector N2.

(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
GND1 – Body ground	Always	Below 1 Ω

(c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
+B – GND1	Always	10 to 14 V
ACC – GND1	Ignition SW ACC	10 to 14 V

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE OR DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05–880 OR 05–892)