05JZ4–01

DIAGNOSTIC TROUBLE CODE CHART

If a normal code is displayed during the DTC check, check the circuit listed for that code in the chart below Proceed to the page given for that circuit.

DTC Code (See Page)	Detection Item	Trouble Area
B1221/21 (05–993)	Power window switch circuit on driver Door	Power window regulator master switch assy (Door ECU)

HINT:

- The DTC shows the switch condition when a DTC is output.
- When a DTC is indicated while the switch is not operated, the switch is assumed to be stuck. When a DTC is not indicated while the switch is operated, the switch contact is assumed to be faulty.