05JZ8–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Power window operation is not possible by operation interlocked with key (only driver side)	1. Front door lock assy RH 2. Power window regulator master switch assy (door ECU)	05–1037 05–995
Operation is not possible after key–OFF (only driver side)	1. Front door courtesy lamp switch assy 2. Multiplex network body ECU	– 05–995
Driver side power window does not operate	1. P FR DOOR fuse 2. ECU–B fuse 3. IG1 fuse 4. Power window regulator master switch assy (door ECU) 5. Power window regulator motor assy RH 6. Wire harness	05–1007 05–1007 05–1007 05–1007 05–1007 05–1007
Window operation with regulator switch for each seat is not possible	1. P FR DOOR fuse 2. D FR DOOR fuse 3. D RR DOOR fuse 4. P RR DOOR fuse 5. Power window regulator master switch assy (door ECU) 6. Power window regulator switch assy 7. Power window regulator motor assy RH 8. Power window regulator motor assy LH 9. Wire harness	05–999 05–999 05–999 05–999 05–999 05–999 05–999 05–999 05–999
Remote operation of other seat with master switch is not possible	1. Power window regulator master switch assy (door ECU) 2. Multiplex network body ECU 3. Wire harness	05–1012 05–1012 05–1012