DTC	B1221/21	POWER WINDOW SWITCH CIRCUIT ON DRIVER DOOR

CIRCUIT DESCRIPTION

This DTC is output when any switch of the power window regulator master switch (door ECU) is operated.

DTC No.	DTC Detection Condition	Trouble Area
B1221/21	Any switch of power window regulator master switch is ON	Power window regulator master switch assy

INSPECTION PROCEDURE

1	CHECK POWER WINDOW REGULATOR MASTER SWITCH ASSY

(a) When the power window regulator master switch is disconnected, a DTC should be output. Check that DTC B1221/21 disappears and that only DTC B1211/11 (driver side door ECU not connected) is output.
   (1) If DTC B1221/21 disappears, proceed to A.
   (2) If DTC B1221/21 is output, proceed to B.

B → REPLACE POWER WINDOW REGULATOR MASTER SWITCH ASSY

A

REPLACE MULTIPLEX NETWORK BODY ECU