05JYM–01

# DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. Proceed to the page given for that circuit.

| DTC No. (See Page) | Detection Item | Trouble Area |
|---|---|---|
| B1222/22 (05–1027) | Door lock switch circuit on driver door | • Power window regulator master switch assy (door ECU)<br>• Front door lock assy RH (driver side)<br>• Multiplex network body ECU |
| B1224/24 (05–1031) | Door lock switch circuit on passenger door | • Door control switch assy (passenger side)<br>• Front door lock assy LH (passenger side)<br>• Multiplex network body ECU |