05JYP–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All doors are not operated by driver's door key cylinder interlocked with key	1. Front door lock assy RH (driver side) 2. Wire harness 3. Power window regulator master switch assy (door ECU)	05–1034
Key lock–in prevention function does not work properly (manual operation and operation interlocked with key are active)	1. Unlock warning switch assy 2. Wire harness 3. Door open warning light (built in combination meter) 4. Front door courtesy lamp switch assy (driver side)	05–1037
Door lock system does not operate at all	1. Door 20 A fuse 2. Multiplex network body ECU 3. Wire harness	05–1137
Door lock system does not operate with manual switch	1. Power window regulator master switch assy (door ECU) (door control switch for manual operation) 2. Multiplex network body ECU 3. Wire harness	05–1137
Malfunction in key confinement prevention function	1. Multiplex network body ECU 2. Unlock warning switch assy 3. Front door courtesy lamp switch assy (driver side) 4. Wire harness	73–2
All doors operate except one	1. Door lock assy 2. Wire harness	73–2