054CK–11

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Engine does not start	1. Power source circuit	05–1091
	2. Wire harness	–
	3. Transponder key ECU assy	–