05JW9–01

# PROBLEM SYMPTOMS TABLE

Proceed to the reference page shown in the table below for each malfunction symptom and troubleshoot each circuit.

| Symptom | Suspected Area | See Page |
|---|---|---|
| Theft deterrent system cannot be set* | 1. ECU power source circuit<br>2. Ignition switch circuit<br>3. Indicator lamp circuit<br>4. Key unlock warning switch circuit<br>5. Back door key lock and unlock switch circuit<br>6. Engine hood courtesy switch circuit | 05–1103<br>05–1105<br>05–1107<br>05–1112<br>05–1115<br>05–1117 |
| Indicator lamp does not blink when theft deterrent system is set* | 1. Indicator lamp circuit | 05–1107 |
| When theft deterrent system is set*<br>(System does not operate when the engine hood is opened) | 1. Engine hood courtesy switch circuit | 05–1117 |
| When theft deterrent system is set*<br>(It is not canceled when the ignition key is turned to ACC or ON position) | 1. Ignition switch circuit | 05–1105 |
| When theft deterrent system is set*<br>(It is still operating when back door is opened with key) | 1. Back door key lock and un–lock switch circuit | 05–1115 |
| While theft deterrent system is in warning operation<br>(Horns do not sound) | 1. Security horn circuit | 05–1110 |
| While theft deterrent system is not set<br>(Horns sound) | 1. Security horn circuit | 05–1110 |

HINT:

- The theft deterrent system is based on the premise that the door lock control system and the wireless door lock control system are operating normally. Check these systems first before troubleshooting the theft deterrent system.

*: For these symptoms, if the suspected areas are found to be functioning normally, replace the theft warning ECU.