05JVN–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Sliding roof does not move when switch is opetated	1. Overhead J/B (Slide roof motor switch) 2. Sliding roof driver gear sub–assy (sliding roof ECU) 3. Wire harness	05–1127