05JWC–01

DIAGNOSTIC TROUBLE CODE CHART

1. BODY ECU DTC

DTC No./Lamp Code (See Page)	Diagnostic Item	Diagnostic Result
B1200/Normal code	Normal	Normal
B1211/11 (05–1142)	Power window regulator master switch assy (door ECU) communication stop	No communication from door ECU for more than 10 seconds
B1214/– (05–1146)	Communication bus +B battery system short	Communication circuit and +B battery system short
B1215/– (05–1146)	Communication bus (body ground) short	Communication bus and body ground short
B1241/41 (05–759)	Body ECU switch circuit diagnosis	Switch is ON or stuck
B1261/– (05–1154)	ECM communication stop	No communication from ECM for more than 10 seconds
B1262/62 (05–1157)	Air conditioner amplifier assy (A/C ECU) communication stop	No communication from A/C ECU for more than 10 seconds
B1269/69 (05–1161)	Theft warning ECU assy (theft deterrent ECU) communication stop	No communication from theft warning ECU for more than 10 seconds
B1271/– (05–1165)	Combination meter assy (meter ECU) communication stop	No communication from meter ECU for more than 10 seconds
B1273/73 (05–1170)	Sliding roof drive gear sub–assy (sliding roof ECU) communication stop	No communication from sliding roof ECU for more then 10 seconds