05JWF–01

PROBLEM SYMPTOMS TABLE

1. TROUBLESHOOTING FOR EACH PROBLEM SYMPTOM

NOTICE:

Confirm the problem symptom and make an inspection with the appropriate flow chart.

Symptom	Suspected Area	See Page
B1211/11 (no communication from door ECU for more than 10 seconds)	1. Power window regulator master switch assy 2. Wire harness	05–1142
B1214 (short in communication circuit and +B power source system)	1. Power window regulator master switch assy 2. ECM 3. A/C amplifier assy 4. Combination meter assy 5. Theft warning ECU 6. Sliding roof drive gear 7. Network gateway ECU 8. Wire harness 9. MPX body ECU	05–1146
B1215 (short in communication circuit and body ground)	1. Power window regulator master switch assy 2. ECM 3. A/C amplifier assy 4. Combination meter assy 5. Theft warning ECU 6. Sliding roof drive gear 7. Network gateway ECU 8. Wire harness 9. MPX body ECU	05–1146
B1261 (no communication from ECM for more than 10 seconds)	1. ECM 2. Wire harness	05–1154
B1262/62 (no communication from A/C ECU for more than 10 seconds)	1. A/C amplifier assy 2. Wire harness	05–1157
B1269/69 (no communication from theft deterrent ECU for more than 10 seconds)	1. Theft warning ECU 2. Wire harness	05–1161
B1271 (no communication from combination meter ECU for more than 10 seconds)	1. Combination meter assy 2. Wire harness	05–1165
B1273/73 (no communication from sliding roof control ECU for more than 10 seconds)	1. Sliding roof drive gear 2. Wire harness	05–1170