05G99-01

HOW TO PROCEED WITH TROUBLESHOOTING

NOTICE:

When DTCs other than U0073/94, U0123/62, U0124/95, U0126/63 are output, inspect and repair the trouble areas indicated by the DTCs.

1	CHECK CAN BUS LINE (SEE PAGE 05–1186)

2	CHECK AND CLEAR DTCs

HINT:
When checking the DTCs for the skid control ECU, proceed to page 05–234.

3	CHECK DTC COMBINATION TABLE (SEE PAGE 05–1185)

4	CIRCUIT INSPECTION

5	IDENTIFICATION OF PROBLEM

6	REPAIR OR REPLACE

7	CONFIRMATION TEST

END