| DTC | P0500/21 | VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION |
|---|---|---|

| DTC | P0503/23 | VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION |
|---|---|---|

## CIRCUIT DESCRIPTION

See page 05–106.

| DTC No. | DTC Detection Condition | Trouble Area |
|---|---|---|
| P0500/21 | This trouble code is output when the vehicle speed signal from the vehicle speed sensor is cut for 0.14 sec. or more while the cruise control is in operation. | • Vehicle speed sensor<br>• Vehicle speed sensor signal circuit<br>• ECM |
| P0503/23 | Momentary interruption and noise are detected when a rapid change of vehicle speed occurs while the cruise control is in operation. | • Vehicle speed sensor<br>• Vehicle speed sensor signal circuit<br>• ECM |

## WIRING DIAGRAM

See page 05–106.

## INSPECTION PROCEDURE

See page 05–106.