160VJ–01

REPLACEMENT

HINT:

The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.

1. DRAIN ENGINE COOLANT (See page 16–7)

2. DISCONNECT RADIATOR RESERVE TANK HOSE OR PIPE

3. DISCONNECT RADIATOR HOSE INLET

4. DISCONNECT RADIATOR HOSE OUTLET

5. DISCONNECT OIL COOLER OUTLET HOSE No. 2

6. DISCONNECT OIL COOLER OUTLET HOSE No. 3

(a) Remove the radiator support upper with the 2 bolts.

7. REMOVE RADIATOR SUPPORT UPPER

8. REMOVE RADIATOR ASSY

(a) Disconnect the fan motor connector.

(b) Disconnect the ECT switch No. 1 connector.

(c) Remove the radiator from the body.

9. REMOVE RADIATOR SUPPORT LOWER

10. REMOVE FAN ASSY W/MOTOR

(a) Remove the 6 bolts and fan from the radiator.

11. INSTALL FAN ASSY W/MOTOR

(a) Install the fan to the radiator with the 6 bolts.

Torque: 7.8 N·m (80 kgf·cm, 69 in.·lbf)

12. INSTALL RADIATOR ASSY

(a) Install the radiator to the body.

(b) Connect the ECT switch No. 1 connector.

(c) Connect the fan motor connector.

13. INSTALL RADIATOR SUPPORT UPPER

(a) Install the radiator support upper with the 2 bolts.

Torque: 12.8 N·m (130 kgf·cm, 9.4 ft·lbf)

14. ADD ENGINE COOLANT (See page 16–7)

15. CHECK FOR ENGINE COOLANT LEAKS (See page 16–1)