CHARGING SYSTEM (3MZ–FE)

190W6–01

PRECAUTION

CAUTION:

- **Check that the battery cables are connected to the correct terminals.**
- **Disconnect the battery cables when the battery is given a quick charge.**
- **Do not perform tests with a high–voltage insulation resistance tester.**
- **Never disconnect the battery while the engine is running.**
- **Check that the charging cable is tightened on terminal B of the generator and the fuse box.**
- **Do not check whether the alternator generates or not with connecting terminal F to the other terminal.**