7013Y–01

# PROBLEM SYMPTOMS TABLE

| Symptom | Suspected Area | See Page |
|---|---|---|
| Rear window defogger does not operate (Indicator lamp On) | 1. Communication function | – |
| | 2. RR DEF M–fuse | – |
| | 3. Defogger relay | 70–27 |
| | 4. Rear window defogger wire | – |
| | 5. Wire harness | – |
| | 6. A/C ECU | 05–429 |
| Rear window defogger does not operate (Indicator lamp OFF) | 1. HEATER fuse | – |
| | 2. A/C control panel | 05–420 |
| | 3. Defogger switch (A/C panel switch) | 05–420 |
| | 4. A/C ECU | 05–429 |
| | 5. Wire harness | – |
| | 6. Gateway ECU | 05–429 |