COMBINATION METER

710MF–01

PROBLEM SYMPTOMS TABLE

Warning Lights:

Symptom	Suspect Area	See page
Check Engine warning light does not come on.	1. ECM 2. Wire Harness or Connector 3. Combination Meter Assy	05–4 – 71–17
Discharge warning light does not come on.	1. ECM 2. Wire Harness or Connector 3. Combination Meter Assy	05–4 – 71–17
Brake warning light does not come on.	1. Skid control ECU 2. Wire Harness or Connector 3. Combination Meter Assy	05–163 – 71–17
ABS warning light does not come on.	1. ABS ECU 2. Wire Harness or Connector 3. Combination Meter Assy	05–163 – 71–17
SRS warning light does not come on.	1. Airbag Sensor Assy Center 2. Wire Harness or Connector 3. Combination Meter Assy	05–504 – 71–17
Open Door warning light does not come on.	1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy	05–795 – 71–17
Fuel Level warning light does not come on.	1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy	05–979 – 71–17
Low Oil Pressure warning light does not come on.	1. Low Oil Pressure Warning Switch 2. Wire Harness or Connector 3. Combination Meter Assy	71–3 – 71–17
Driver's seat belt warning light does not come on.	1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy	05–984 – 71–17
"OIL LEVEL" warning light does not come on.	1. Low Oil Level Sensor 2. Wire Harness or Connector 3. ECM 4. Combination Meter Assy	05–4 – 05–4 71–17

Indicator Lights:

Symptom	Suspect Area	See page
Turn indicator light does not come on.	1. Turn Signal and Hazard Warning System 2. Wire Harness or Connector 3. Combination Meter Assy	05–746 – 71–17
High Beam indicator light does not come on.	1. Headlight Dimmer Switch 2. Wire Harness or Connector 3. Combination Meter Assy	05–746 – 71–17
Washer level indicator light does not come on.	1. Washer Level Warning Switch 2. Wire Harness or Connector 3. Combination Meter Assy	– – 71–17
All buzzer (key reminder, tail cancel, Seat belt) does not operate.	1. Refer to troubleshooting 2. Combination Meter Assy	05–965 71–17
O/D OFF indicator light does not come on.	1. O/D off Select Switch 2. Wire Harness or Connector 3. Combination Meter Assy	05–415 – 71–17
SLIP indicator light does not come on.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	– 05–163 71–17

VSC indicator light does not come on.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	– 05–163 71–17
A/T OIL TEMP indicator light does not come on.	1. Wire Harness or Connector 2. Automatic transmission 3. Combination Meter Assy	– 05–343 71–17
ECT SNOW indicator light does not come on.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	– 05–4 71–17
A/T shift indicator light does not come on.	1. Park Neutral Position Switch 2. Wire Harness or Connector 3. ECM 4. Combination Meter Assy	05–343 – 05–4 71–17
”CRUISE” indicator light does not come on.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	– 05–4 71–17

Meter Gauges:

Symptom	Suspect Area	See page
Speedometer does not operate.	1. Refer to troubleshooting	05–973
Tachometer does not operate.	1. Refer to troubleshooting	05–976
Fuel Gauge does not operate or operates abnormally.	1. Refer to troubleshooting	05–979
Water temperature does not operate.	1. Refer to troubleshooting	05–982