LUGGAGE COMPARTMENT DOOR GARNISH SUB–ASSY OUTSIDE

76181–01

REPLACEMENT

1. REMOVE BACK WINDOW PANEL TRIM UPPER (See page 75–20)
2. REMOVE BACK DOOR TRIM COVER RH (See page 75–20)
3. REMOVE BACK DOOR TRIM COVER LH (See page 75–20)
4. REMOVE BACK DOOR TRIM PANEL ASSY (See page 75–20)
5. REMOVE REAR SPOILER (W/ REAR SPOILER) (See page 75–20)
6. REMOVE BACK DOOR LOCK ASSY (See page 75–20)
7. REMOVE BACK DOOR HANDLE ASSY OUTSIDE (See page 75–20)
8. REMOVE LUGGAGE COMPARTMENT DOOR GARNISH SUB–ASSY OUTSIDE
(a) Remove the 5 screws and the 2 licence plate lights.
(b) Remove the nut and garnish.
9. INSTALL LUGGAGE COMPARTMENT DOOR NAME PLATE NO.1
(a) Using white gasoline, clean the garnish installation surface.
(b) Using a heat light, heat the garnish and name plate between 20 to 30°C (68 to 86°F).
(c) Install the name plate.

NOTICE:
Do not heat the garnish and name plate excessively.