■CUSTOMIZED BODY ELECTRONIC FUNCTION

1. General

An intelligent tester can be used to customize the system settings.

2. Customized Table for Lighting System

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Lighting Time	Changes the lighting time after closing the door. (It will quickly fade out in the event the power source is turned IG-ON.)	15 sec.	7.5 sec./ 15 sec./ 30 sec.
I/L ON W/Door Key Unlock	Lights up the interior lights, etc. when the door is unlocked with a transmitter, key cylinder or door lock control switch.	ON	ON/OFF
I/L ON/ACC OFF	Lights up the interior lights when the power source is operated from “ACC” to “OFF”.	ON	ON/OFF
Sensitivity	To adjust the sensitivity of the lighting illumination.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
Disp Ex ON Sen	Used to changes the brightness required to dim the lights such as the indicator light of the combination meter assembly, A/C indicator lights, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
Disp Ex OFF Sen	Used to change the brightness required to cancel the dimming of the lights such as the indicator light of the combination meter assembly, A/C indicator lights, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
Mirr-Foot-Lgt Approached*	Function to switch on foot light when the owner approaches the vehicle.	ON	ON/OFF
Mirr-Foot-Lgt Unlocked*	Function of lighting foot light attached to outside rear view mirrors when vehicle is unlocked with door control transmitter, key or by hand.	ON	ON/OFF
Mirr-Foot-Lgt w/Master SW*	Function of lighting foot light attached to outside rear view mirrors when vehicle is unlocked with power door lock switch in the vehicle.	ON	ON/OFF
Mirror foot light Time*	Changes the time the foot lights stay on.	15 sec.	7.5 sec./ 15 sec./ 30 sec./ OFF

*: Models for China

3. Customized Table for Combination Meter Assembly

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Key Reminder Buzzer Volume	Changes the volume of the key reminder buzzer.	LARGE	LARGE/ MEDIUM/ SMALL
Key Reminder Buzzer Sound	Changes the frequency of the key reminder buzzer.	SLOW	NORMAL/ FAST/ SLOW
Units By Region	Function to change the unit of the display.	Km/L	Km/L/ MI/G
Seat-belt Warning Buzzer	Function to change the seatbelt reminder buzzer.	ON	ON/OFF
Seat-belt Warning Buzzer	Function to change the seatbelt reminder buzzer.	ON	ON/OFF

4. Customized Table for Automatic Air Conditioning System

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Air Inlet Mode	When the A/C is turned ON and it is desired to make the compartment cool down quickly, this is the function to set the mode automatically to RECIRCULATE mode.	AUTO	MANUAL/ AUTO
Compressor Mode	Turns the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF.	AUTO	MANUAL/ AUTO
Compressor/Air Inlet DEF operation	Turns the A/C ON automatically linking with the FRONT DEF button when the A/C is OFF.	LINK	NORMAL/ LINK
Evaporator Control	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows fogging up.	AUTO	MANUAL/ AUTO
Foot/DEF Auto Mode	Turns the air flow to FOOT/DEF ON automatically when AUTO MODE is ON.	ON	ON/OFF
Foot/DEF Automatic Blower Increase Function	Function to increase the blower level automatically when the defroster is ON.	ON	ON/OFF
Set Temperature Shift	Shifts the climate control output air temperature compared to the displayed temperature.	NORMAL	+2°C/+1°C/ NORMAL/ −1°C/ −2°C
Ambient Temperature Shift	To shift the ambient temperature that is detected against the displayed ambient temperature.	NORMAL	+3°C/+2°C/ +1°C/ NORMAL/ −1°C/-2°C/ −3°C

5. Customized Table for Door Lock Control System

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Unlock w/2 Times D Key Operation*1	Unlocks only the driver's door by operating the key once and unlocks all the doors when the key is operated twice. In the OFF setting, operating the key "UNLOCK" once makes all the doors unlock.	OFF	ON/OFF
Auto Lock*2	Locks the doors when the vehicle reaches a certain speed.	OFF	ON/OFF
Auto Lock/Shift Not P*2	Locks the doors when the shift lever is moved from P position to the position other than P.	ON	ON/OFF
Auto Unlock/Shift P*2	Unlocks the doors when the shift lever is moved from the position other than P position to the P position.	ON	ON/OFF
All Unlock w/D Door Open-Close*2	Unlocks all the other doors when the driver's door is opened within 10 seconds after turning the power source to OFF from IG-ON.	OFF	ON/OFF

*1: Models for Australia *2: Models for China

6. Customized Table for Wireless Door Lock Control System

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Wireless door lock control function	Turns the wireless door lock function on or off.	ON	ON/OFF
Hazard answer back of the wireless	Lights up the all turn signal lights once when the transmitter lock button is pressed, and twice when the unlock button is pressed.	ON	ON/OFF
Wireless buzzer response*	Turns the wireless door lock buzzer response function on or off.	ON	ON/OFF
Open door warning*	Makes the wireless door lock buzzer sound for 10 seconds if the door is open when locking with the wireless door lock function.	ON	ON/OFF
2 times operation wireless unlock*	Unlocks the driver's door when the unlock button of the transmitter is pressed once and unlocks all the doors when it is pressed twice. In the OFF setting, pressing one time makes all the doors unlock.	OFF	ON/OFF
Auto Lock Time	To change the time until re-locking after unlocking with the wireless door lock function.	30 sec.	30 sec./ 60 sec.
Panic Function*	Operates the theft deterrent system horn and lights when the lock button of the transmitter is pressed for 2.5 seconds. If there is a separate panic button, the panic button will be used instead of the lock button.	ON	ON/OFF
Wireless Glass Hatch Open	Function to permit opening the glass hatch with the door control transmitter.	0.6 sec.	ON/ 0.6 sec./ 0.8 sec./ 2 times/ OFF

*: Models for Australia

7. Customized Table for Smart Entry and Start System

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Ignition Available Area	Setting an actuation area of smart entry and start system.	ALL	ALL/ FRONT
Park Wait Time	Sets a wait time to permit opening a door after it has been locked.	2.5 sec.	0.5 sec./ 1.5 sec./ 2.5 sec./ 5.0 sec.
Back Door Opening Operation	Function to open the back door when the key is actuation are.	Long	Long/ Twice/ OFF
Panic Alarm Function*	Operates the theft deterrent system horn and lights when the lock button of the key is pressed for 2.5 seconds. If there is a separate panic button, the panic button will be used instead of the lock button.	ON	ON/OFF
Passenger Take Key	Function to warn that a key is taken out by fellow passengers (It means that the key is taken out from except the driver's door), when power source is not OFF.	ON	ON/OFF
Key Low Battery Warning	Function to set a warning function for the time when a key battery becomes weak.	ON	ON/OFF
Key Out Range Warning	Function to set a warning function for trying to start the engine before key is still out of its Range.	ON	ON/OFF

*: Models for Australia

8. Customized Table for Theft Deterrent System

Intelligent Tester Display Content	Contents	Default Setting	Available Setting
Warning by vehicle's horn*	Function to make the warning by the horn and security horn available.	ON	ON/OFF

*: Models for Australia