■ FUNCTION OF MAIN COMPONENTS

Component		Function
Rear Display		• Displays DVD output images, video CD output images, adjustment screen, option screen, and diagnosis screen. • Receives signals from remote control. • Outputs audio signals to the wireless headphone in the form the infrared signals.
	RSE ECU	Processes audio and visual signals from the DVD player, and outputs them.
	DVD Player	Outputs the audio and visual signals to the RSE ECU.
Remote Control		Outputs various control signals for the RSES to the rear display in the form of infrared signals.
Navigation Receiver Assembly		• Receives visual signals from the rear display and displays them. • Receives audio signals from the rear display and outputs them to the speakers. • Child lock function (disables operation of the RSES through the remote control or panel buttons on the rear display) on/off by the screen setting. • RSES on/off from front seat by the adjustment screen.