■ FUNCTIONS

The theft deterrent system has the following functions:

Function	Outline
Alarm	When the theft deterrent system is switched to the alarm state, the warning items are operated and the alarm sounds for approximately 30 seconds.
Alarm Indicator	When the state of the theft deterrent system is switched to the armed preparation state or alarm state, the security indicator light is illuminated to inform the user. This indicator is also the engine immobilizer indicator, which blinks when in the engine immobilizer set state.
Forced Door Lock	The Main Body ECU (Instrument Panel Junction Block) transmits a door lock signal to all the doors when all the following conditions are satisfied. • The theft deterrent system is in the alarm state. • There is no key inserted in the ignition key cylinder. (without Smart Entry and Start System) • There is no key in the actuation area. (with Smart Entry and Start System) • One of the front doors has been unlocked. The function stops when one of the following conditions is met. • All doors are locked. • The warning ends after approximately 30 seconds. • The ignition key is inserted in the ignition key cylinder. (without Smart Entry and Start System) • The key is in the actuation area. (with Smart Entry and Start System)
Panic Control (Models for Australia)	When the PANIC button of the door control transmitter*1/key*2 is pressed, the Main Body ECU (Instrument Panel Junction Block) operates the alarm function.

*1: Models without Smart Entry and Start System *2: Models with Smart Entry and Start System