5. PROCEDURES NECESSARY WHEN BATTERY TERMINAL IS DISCONNECTED/RECONNECTED

(a) THE WORK LIST: USA, Canada

(1) Each inspection procedure refers to TOYOTA Repair Manual.

Necessary Procedures	Procedure Details	Effects/Inoperative Functions When Necessary Procedures are not Performed	Notes
Reset back door close position	Fully close the back door to turn off the courtesy switch.	Power back door function	If the back door is closed when disconnecting the cable from the battery terminal, it is not necessary to reset it.

NOTICE:
It may not be possible to release the steering lock or start the engine when the battery voltage is low. If this occurs, initialization of the steering lock system is required.

(b) THE WORK LIST: Except USA, Canada

(1) Each inspection procedure refers to the TOYOTA Repair Manual.

Necessary Procedures	Procedure Details	Effects/Inoperative Functions When Necessary Procedures are not Performed	Notes
Correction of steering angle neutral point	Fully turn the steering wheel to the right and left.	Parking guidance function	—
Reset back door close position	Fully close the back door to turn off the courtesy switch.	Power back door function	If the back door is closed when disconnecting the cable from the battery terminal, it is not necessary to reset it.

NOTICE:
It may not be possible to release the steering lock or start the engine when the battery voltage is low. If this occurs, initialization of the steering lock system is required.