■CUSTOMIZED BODY ELECTRONIC FUNCTION

1. General

An intelligent tester or Techstream* can be used to customize the system settings.

*: Techstream is the name for the diagnostic tester in North America, but other countries will continue to use the intelligent tester.

2. Customized Table for Lighting System

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
LIGHTING TIME (Lighting Time)	Changes the lighting time after closing the door. (It will quickly fade out in the event the power source is turned IG-ON.)	15 sec.	7.5 sec./ 15 sec./ 30 sec.
I/L ON/UNLOCK (Light Dome Lamp When Unlocking With Door Key)	Lights up the interior lights, etc. when the door is unlocked with a transmitter, key cylinder or door lock control switch.	ON	ON/OFF
I/L ON/ACC OFF (Light he I/L when ACC OFF)	Lights up the interior lights when the power source is operated from “ACC” to “OFF”.	ON	ON/OFF
LIGHT OFF DELAY (Light auto OFF delay)	Keeps the headlights illuminated for a certain period of time after closing all the doors when the power source has been turned OFF (was in the ON mode), the light control switch is in the HEAD or AUTO position and the headlights were ON.	30 sec.	OFF/ 30 sec./ 60 sec./ 90 sec.
SENSITIVITY (Turn ON luminous intensity)	To adjust the sensitivity of the lighting illumination.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
DISP EX ON SEN (Display extinction luminous intensity)	Used to changes the brightness required to dim the lights such as the indicator light of the combination meter assembly, A/C indicator lights, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
DISP EX OFF SEN (Display extinction release luminous intensity)	Used to change the brightness required to cancel the dimming of the lights such as the indicator light of the combination meter assembly, A/C indicator lights, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
MIRR F/L APRCHD* (M/F/L Aprchd)	Function to switch on foot light when the owner approaches the vehicle.	ON	ON/OFF
MIRR F/L UNLOCK* (M/F/L Unlock)	Function of lighting foot light attached to outside rear view mirrors when vehicle is unlocked with door control transmitter, key or by hand.	ON	ON/OFF

*: Models for Smart Key System

(Continued)

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
MIRR F/L MSTR S* (Mirr-Foot-Lgt w/Master SW)	Function of lighting foot light attached to outside rear view mirrors when vehicle is unlocked with power door lock switch in the vehicle.	ON	ON/OFF
MIRR F/L TIME* (M F/L Time)	Changes the time the foot lights stay on.	15 sec.	7.5 sec./ 15 sec./ 30 sec./ OFF

*: Models for Smart Key System

3. Customized Table for Combination Meter Assembly

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
KEY REMND VOLUM (Key Reminder Buzzer Volume)	Changes the volume of the key reminder buzzer.	LARGE	LARGE/ MEDIUM/ SMALL
KEY REMND SOUND (Key Reminder Buzzer Sound)	Changes the frequency of the key reminder buzzer.	SLOW	NORMAL/ FAST/ SLOW
UNITS BY REGION (Units By Region)	Function to change the unit of the display.	MI/G	Km/L/ MI/G
D-SEATBELT WARN (Seat-belt Warning Buzzer)	Function to change the seatbelt reminder buzzer.	ON	ON/OFF
P-SEATBELT WARN (Seat-belt Warning Buzzer)	Function to change the seatbelt reminder buzzer.	ON	ON/OFF

4. Customized Table for Automatic Air Conditioning System

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
AIR INLET MODE (Air Inlet Mode)	When the A/C is turned ON and it is desired to make the compartment cool down quickly, this is the function to set the mode automatically to RECIRCULATE mode.	AUTO	MANUAL/ AUTO
COMPRESSOR MODE (Compressor Mode)	Turns the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF.	AUTO	MANUAL/ AUTO
COMPRS/DEF OPER (Compressor/Air Inlet DEF operation)	Turns the A/C ON automatically linking with the FRONT DEF button when the A/C is OFF.	LINK	NORMAL/ LINK
EVAP CTR (Evaporator Control)	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows fogging up.	AUTO	MANUAL/ AUTO
FOOT/DEF MODE (Foot/DEF Auto Mode)	Turns the air flow to FOOT/DEF ON automatically when AUTO MODE is ON.	ON	ON/OFF
AUTO BLOW UP (Foot/DEF Automatic Blower Increase Function)	Function to increase the blower level automatically when the defroster is ON.	ON	ON/OFF
SET TEMP SHIFT (Set Temperature Shift)	Shifts the climate control output air temperature compared to the displayed temperature.	NORMAL	+2°C/+1°C/ NORMAL/ −1°C/ −2°C
AMBIENT TMP SFT (Ambient Temperature Shift)	To shift the ambient temperature that is detected against the displayed ambient temperature.	NORMAL	+3°C/+2°C/ +1°C/ NORMAL/ −1°C/-2°C/ −3°C

5. Customized Table for Door Lock Control System

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
UNLK/KEY TWICE (Unlock w/2 Times D Key Operation)	Unlocks only the driver's door by operating the key once and unlocks all the doors when the key is operated twice. In the OFF setting, operating the key "UNLOCK" once makes all the doors unlock.	ON	ON/OFF
AUTO LOCK (Auto Lock)	Locks the doors when the vehicle reaches a certain speed.	OFF	ON/OFF
AUTO LOCK/SHIFT (Auto Lock/Shift Not P)	Locks the doors when the shift lever is moved from P position to the position other than P.	ON	ON/OFF
AUTO UNLOCK/SHIFT (Auto Unlock/Shift P)	Unlocks the doors when the shift lever is moved from the position other than P position to the P position.	ON	ON/OFF
ALL UNLK/OPN-CL (All Unlock w/D Door Open-Close)	Unlocks all the other doors when the driver's door is opened within 10 seconds after turning the power source to OFF from IG-ON.	OFF	ON/OFF

6. Customized Table for Wireless Door Lock Control System

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
WIRELESS OPER (Wireless door lock control function)	Turns the wireless door lock function on or off.	ON	ON/OFF
HAZARD ANS BACK (Hazard answer back of the wireless)	Lights up the all turn signal lights once when the transmitter lock button is pressed, and twice when the unlock button is pressed.	ON	ON/OFF
WIRLS BUZZ RESP (Wireless buzzer response)	Turns the wireless door lock buzzer response function on or off.	ON	ON/OFF
OPEN DOOR WARN (Open door warning)	Makes the wireless door lock buzzer sound for 10 seconds if the door is open when locking with the wireless door lock function.	ON	ON/OFF
UNLOCK/2 OPER (2 times operation wireless unlock)	Unlocks the driver's door when the unlock button of the transmitter is pressed once and unlocks all the doors when it is pressed twice. In the OFF setting, pressing one time makes all the doors unlock.	ON	ON/OFF
AUTO LOCK DELAY (Auto Lock Time)	To change the time until re-locking after unlocking with the wireless door lock function.	60 sec.	30 sec./ 60 sec.
ALARM FUNCTION (Panic Function)	Operates the theft deterrent system horn and lights when the lock button of the transmitter is pressed for 2.5 seconds. If there is a separate panic button, the panic button will be used instead of the lock button.	ON	ON/OFF

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
WIRLS AUTO LOCK (Wireless Auto Lock)	Function of auto-locking the doors after 30/60 seconds after opening them by unlock button on the transmitter.	ON	ON/OFF
WIRLS GLS HATCH (Wireless Glass Hatch Open)	Function to permit opening the glass hatch with the door control transmitter.	0.6 sec.	ON/ 0.6 sec./ 0.8 sec./ 2 times/ OFF

7. Customized Table for Smart Key System

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
IGNITION AREA (Ignition Available Area)	Setting an actuation area of smart key system.	ALL	ALL/ FRONT
PARK WAIT TIME (Park Wait Time)	Sets a wait time to permit opening a door after it has been locked.	2.5 sec.	0.5 sec./ 1.5 sec./ 2.5 sec./ 5.0 sec.
BACK DOOR OPER (Back Door Opening Operation)	Function to open the back door when the key is actuation area.	Long	Long/ Twice/ OFF
ALARM FUNCTION (Panic Alarm Function)	Operates the theft deterrent system horn and lights when the lock button of the key is pressed for 2.5 seconds. If there is a separate panic button, the panic button will be used instead of the lock button.	ON	ON/OFF
WARNING 3 (Passenger Take Key)	Function to warn that a key is taken out by fellow passengers (It means that the key is taken out from except the driver's door), when power source is not OFF.	ON	ON/OFF
KEY LOW-BATT WARN (Key Low Battery Warning)	Function to set a warning function for the time when a key battery becomes weak.	ON	ON/OFF
WARNING 6 (Key Out Range Warning)	Function to set a warning function for trying to start the engine before key is still out of its Range.	ON	ON/OFF

8. Customized Table for Theft Deterrent System

Intelligent Tester (Techstream) Display Content	Contents	Default Setting	Available Setting
WARN BY HORN (Warning by vehicle's horn)	Function to make the warning by the horn and security horn available.	ON	ON/OFF
PASSIVE MODE (Passive mode (Security system))	PASSIVE MODE is the function used to set the theft deterrent system automatically 30 seconds after closing the driver's door when the door was opened after removing the key from the key cylinder.	OFF	ON/OFF
ENTRY DELAY (Entry Delay)	To change the entry delay time (period before starting the warning) for the passive mode.	14 sec.	0 sec./ 14 sec./ 30 sec.