■ FUNCTION

1. General

- The customize setting can be turned ON/OFF using the customized body electronics system. For details, see page BE-21.
- The wireless door lock control system has the following functions and customizes:

×: Standard (Non customizable) *: Customizable

Function	Outline	Customizable
All Doors Lock	Pressing the LOCK button of the door control transmitter locks the doors.	*1
All Doors Unlock (2-step Unlock)	Pressing the UNLOCK button of the door control transmitter twice within 3 seconds unlocks all doors after it first unlocks the driver's door.	*1
All Doors Unlock (1-step Unlock)	This function is provided to unlock all the doors when the key is turned in the key cylinder one time.	*2
Power Back Door Open/Close	Keeping the power back door button of the door control transmitter pressed longer than about 0.8 seconds opens or closes the back door.	*1
Glass Hatch Open	Keeping the glass hatch button of the door control transmitter pressed longer than about 0.6 seconds opens the glass hatch.	*1
Answer Back	When the doors are being locked or unlocked through the operation of the door control transmitter, the wireless door lock buzzer sounds and the hazard lights blinks once during locking and twice during unlocking. Also, the answer back function operates when the doors are locked by the auto relock function.	*1
Answer Back (For Power Back Door)	When the door control transmitter is used for opening or closing the power back door is operated, this function sounds once the wireless door lock buzzer and power back door buzzer to inform the user that the operation has been started.	*1
Panic Alarm	Keeping the PANIC button of the door control transmitter pressed longer than about 0.8 seconds causes the following to activate as an alarm. • Sounds the horn and security horn. • Flashes the hazard lights, headlights, and taillights. • Illuminates the interior light (Switch is in the DOOR position).	*1
Automatic Relock	If none of the doors are opened within 60 seconds after they are unlocked using the wireless door lock remote control, all the doors will be locked again automatically.	*1

*1: Default setting is on. *2: Default setting is off.

(Continued)

Function	Outline	Customizable
Repeat	If a door is not locked in response to the locking operation of the door control transmitter, the Main Body ECU (Instrument Panel Junction Block) will output a lock signal again after 1 second passes.	×
Security	Sends a door lock/unlock operation request signal as a rolling code.	×
Door Ajar Warning	If any door is open or ajar, pressing the LOCK button of the door control transmitter will cause the wireless door lock buzzer to sound for about 10 seconds as a warning.	×
Diagnosis	If there is a malfunction in the system, the Main Body ECU (Instrument Panel Junction Block) stores the DTCs (Diagnostic Trouble Codes) in its memory. For details, see the 2008 HIGHLANDER Repair Manual (Pub. No. RM06J0U).	×