SEAT BELT REMINDER SYSTEM

■ DESCRIPTION

If a seat belt is not fastened, this system flashes the seat belt reminder light or sounds the buzzer in the combination meter assembly as a reminder.

- When the power source is turned to the IG-ON position, this system detects the condition of the seat belts based on the signals indicated below.
- The seat belt reminder buzzer for the front passenger can be cancelled. However, the legally mandated minimum operation of the buzzer cannot be cancelled. For details, see page BE-226.

Seat	Base Signal	Reminder Method
Driver	Front Seat Inner Belt Assembly (Driver Side Seat Belt Buckle Switch) (Non-contact Type)	• Buzzer sounds • Reminder light flashes
Front Passenger	• Front Seat Inner Belt Assembly (Front Passenger Side Seat Belt Buckle Switch) (Non-contact Type) • 4 Occupant Classification Sensors (Though the Occupant Classification ECU)	• Buzzer sounds • Reminder light flashes

Service Tip

Buzzer Reminder Cancel Mode Setting

Buzzer reminder cancel mode can be set using an intelligent tester or Techstream*. For details, see the 2008 HIGHLANDER Repair Manual (Pub. No. RM06J0U).

*: Techstream is the name for the diagnostic tester in North America, but other countries will continue to use the intelligent tester.