■ FUNCTION

The following table shows the mode and the indicator light operation.

Mode	Outline	Indicator Light
Transmission Mode	While the switch is being pressed, the garage door opener transmits the code that was previously registered. Even if the button is pressed continuously, the transmission stops after 20 seconds.	Flash → ON (Rolling Code) ON (Except Rolling Code)
Learning Mode	When the button is pressed continuously for 20 seconds, the mode changes to a learning mode in which a transmitter code can be registered. In this mode, a new transmitter code can be registered or an existing code can be overwritten. If no codes are registered within 90 seconds after entering the learning mode, the mode changes to a low power mode.	Slow Flashing (During Learning Mode) Quick Flashing (Registration Completed)
All Delete Mode	When the 2 outer garage door opener switches are pressed simultaneously for 20 seconds, all the transmitter codes that are registered to the three switches are cleared. By releasing these switches within 10 seconds after clearing the codes, the switches will automatically select learning mode the next time they are pressed. By keeping these switches pressed for longer than 10 seconds after clearing the codes, all these switches will be registered with a code for operation verification.	Quick Flashing (Code Clearing Completed)
Low Power Mode	If a switch remains pressed longer than 100 seconds, such as in the case in which the pressed switch does not release itself, the low power mode will be automatically selected to reduce power consumption.	OFF