SMART KEY SYSTEM

■ DESCRIPTION

The smart key system has the following main functions, making it a very user-friendly system. This system is standard equipment on all models.

Function		Outline
Start Function (See page BE-135)		The start function is operated by simply pressing the power switch while carrying the key. When the power switch is pressed, the main body ECU (instrument panel junction block) turns on/off the ACC relay, IG1 relay, and IG2 relay to switch the power source pattern. • The power source pattern changes depending on depression of the brake pedal and the shift lever position. For details, see page BE-140.
	HV Immobilizer	The HV immobilizer function compares the ID code that is registered in the immobilizer code ECU with the ID code of the transponder chip that is embedded in the key.
	Steering Lock	The steering lock function locks and unlocks the steering wheel using the lock/unlock motor in the steering column assembly.
Entry Function (See page BE-150)		**[Entry Unlock]** The doors unlock if the front outside door handle is gripped. • The driver's outside door handle unlocks the driver's door. • The front passenger door outside door handle unlocks all doors and the back door. **[Entry Lock]** All doors lock if the lock switch on the front outside door handle or back door is pushed.
	Back Door Open Function	The back door can be opened manually by simply pressing the back door opener switch.
	Glass Hatch Open Function	The glass hatch can be opened manually by simply pressing the glass hatch opener switch.
	Wireless Door Lock Control	The wireless door lock control function is convenient for locking and unlocking all the doors and back door at a distance. The basic operation is the same as that in the wireless door lock control system.