■ FUNCTIONS

The theft deterrent system has the following functions:

Function	Outline
Alarm	When the theft deterrent system is switched to the alarm state, the warning items are operated and the alarm sounds for approximately 60 seconds.
Alarm Indicator	When the state of the theft deterrent system is switched to the armed preparation state or alarm state, the security indicator light is illuminated to inform the user. This indicator also operates as the HV immobilizer indicator, which blinks when in the HV immobilizer set state.
Forced Door Lock	The main body ECU (instrument panel junction block) transmits a door lock signal to all the doors when all the following conditions are satisfied. • The theft deterrent system is in the alarm state. • There is no key in the actuation area. • One of the front doors has been unlocked. The function stops when one of the following conditions is met. • All doors are locked. • The warning ends after approximately 60 seconds. • The key enters the actuation area.
Alarm Memory	In order to inform the user that the theft deterrent system was switched to the alarm state, the main body ECU (instrument panel junction block) illuminates the taillights for 2 seconds when the system is switched to the disarmed state.
Panic Control	When the PANIC button of the key is pressed, the main body ECU (instrument panel junction block) operates the alarm function.
Passive Mode	When the user forgets to lock the doors, the theft deterrent system locks them. (When the user closes all the doors, the theft deterrent system will lock all the doors after a delay.)