SEAT BELT WARNING SYSTEM

■ DESCRIPTION

If a seat belt is not fastened, this system flashes the seat belt warning light or sounds the buzzer in the combination meter assembly as a warning.

- When the power source is turned to the IG-ON position, this system detects the condition of the seat belts based on the signals indicated below.
- The seat belt warning buzzer for the front passenger can be cancelled. However, the legally mandated minimum operation of the buzzer cannot be cancelled. For details, see page BE-215.

Seat	Base Signal	Warning Method
Driver	Front Seat Inner Belt Assembly (Driver Side Seat Belt Buckle Switch) (Non-contact Type)	• Buzzer sounds • Warning light flashes
Front Passenger	• Front Seat Inner Belt Assembly (Front Passenger Side Seat Belt Buckle Switch) (Non-contact Type) • 4 Occupant Classification Sensors (Though the Occupant Classification ECU)	• Buzzer sounds • Warning light flashes

Service Tip

Buzzer Warning Cancel Mode Setting

Buzzer warning cancel mode can be set using Techstream. For details, see the 2008 HIGHLANDER HYBRID VEHICLE Repair Manual (Pub. No. RM07V0U).