TIRE PRESSURE WARNING SYSTEM

■ DESCRIPTION

When the tire pressure warning system detects that the pressure of a tire becomes lower than the threshold, it will turn on the tire pressure warning light to warn the driver.

- The tire pressure warning antenna and receiver receives the tire inflation pressure, temperature, and ID number information from the 4 or 5 (which includes the standard type spare tire*) tire pressure warning valve and transmitters and transmits this information to the tire pressure warning ECU.
- The tire pressure warning ECU monitors each tire pressure warning valve and transmitter to detect low tire inflation pressure.

*: Optional Equipment

▶ System Diagram ◀

